

**Key to auxiliary circuit diagram - Bonneville,  
Bonneville T100, Scrambler & Thruxton**

Item number	Description
1	Fuses 2 & 3
2	Accessory socket
3	Direction indicator unit
4	Ignition switch
5	Fuse 7
6	Front brake lever switch
7	Left hand switch cube
8	Horn button
9	Direction indicator switch
10	Horn
11	Rear brake lever switch
12	Rear light
13	Brake light
14	Left hand rear direction indicator
15	Right hand rear direction indicator
16	Instrument assembly
17	Indicator warning light
18	Alarm LED
19	Alarm control unit
20	Right hand front indicator
21	Left hand front indicator

Wire colour codes	
B	Black
U	Blue
N	Brown
G	Green
S	Slate grey
O	Orange
K	Pink
R	Red
P	Purple
W	White
Y	Yellow
LG	Light green
LU	Light blue

### Auxiliary Circuit - Bonneville, Bonneville T100, Scrambler & Thruxton

